



















Dell™ OptiPlex™ | FX160 Re-Imaging Guide









Dell™ OptiPlex™ FX160 Re-Imaging Guide



Model DC01T

www.dell.com | support.dell.com





Notes, Notices, and Cautions



NOTE: A NOTE indicates important information that helps you make better use of your computer.



NOTICE: A NOTICE indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



CAUTION: A CAUTION indicates a potential for property damage, personal injury, or death.

If you purchased a Dell™ n Series computer, any references in this document to Microsoft® Windows® operating systems are not applicable.



Information in this document is subject to change without notice.

© 2008 Dell Inc. All rights reserved.

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: *Dell*, the *DELL* logo, and *OptiPlex* are trademarks of Dell Inc.; *Microsoft*, *Windows*, *Windows Vista*, and the *Windows Vista* start button are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.


Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.


Model DC01T

August 2008

P/N H310K

Rev. A01





Dell™ OptiPlex™ FX160 Re-Imaging Guide


The Dell OptiPlex FX160 computer with an internal flash card hard drive is preloaded with either a Microsoft® Windows® XP Embedded or SUSE® Linux Enterprise Thin Client (SLETC) operating system. However, when system updates are released, or special configurations are required, the internal FX160 flash card or hard drive can be re-imaged.

Re-Imaging the FX160 Computer With Microsoft Windows


For the FX160 Windows XP Embedded operating system, updates are provided on a bootable DVD. Booting the FX160 computer from the DVD opens a utility that writes the FX160 flash card. Additional software, such as drivers for a wireless card, are loaded separately.


The DVD update disk can be transferred to a bootable USB flash drive using a Windows system with Microsoft Windows Automation Installation Kit (WAIK) software. The update can then be installed on the FX160 flash card when booting the FX160 computer from the USB flash drive.


Re-Imaging an FX160 Computer With the Update DVD

 **CAUTION: Re-imaging your FX160 computer will erase all data from the hard drive or flash card. Back up your system to an external device before re-imaging your computer.**

- 1 Power off the FX160 computer.
- 2 Attach an external USB DVD reader drive to the FX160 computer.
- 3 Power on the FX160 computer. When the BIOS window options list appears (in the upper right-corner of the screen) press <F12> to access the Boot Device menu.
- 4 In the Boot Device selection window, use the arrow keys to highlight the DVD drive you attached.
- 5 Insert the bootable Windows update DVD into the DVD reader and press **Enter**. A Windows Preinstallation Environment (PE) system will initialize.
- 6 To save the current FX160 system image, click the **Capture System Image** button and follow the prompts to write the system image to an external device. When the capture operation completes, the imaging tool window reappears.






 **NOTICE:** By default, all existing files are erased and system images are installed on the first available boot drive as configured in the BIOS System Boot Device Priority. Back up your system to an external device before re-imaging your computer

- 7 To install a new system image, click the **Install System Image** button. In the browse window, select the system image to install, then click **Install**.
- 8 When the installation completes, restart the system, booting from the drive that was imaged.

Re-Imaging an FX160 Computer With the a Bootable USB Flash Drive (UFD)

The FX160 computer can be re-imaged with a bootable Windows PE RAM Disk on a UFD. This UFD is built manually.


Create a Bootable Windows UFD Device




 **CAUTION:** Re-imaging your FX160 computer will erase all data from the hard drive or flash card. Back up your system to an external device before re-imaging your computer.


What you will need:

- A workstation computer with Microsoft Vista or Microsoft XP that provides all tools and source files.
- Access to a computer running Windows Vista or a Windows PE session.
- A UFD device. The size of the UFD device must be at least 64MB larger than your Windows PE image plus any additional files that you include.
- FX160 Windows update DVD.

Use the `Copype.cmd` script to create a bootable Windows PE RAM disk on a UFD device. With Windows PE RAM a computer can be restarted for deployment or recovery.

 **NOTE:** Ensure that you have sufficient memory to support the size of your Windows PE image and any additional applications.




 **NOTE:** For additional information about this procedure, see the *Windows Preinstallation Environment User Guide* sections "Include a Custom Script in a Windows PE Image" and "Walkthrough: Create a Custom Windows PE Image". This information is part of the help system of the WAIK software.

- 1 Download and install the latest version of Microsoft WAIK software onto the workstation computer.

 **NOTE:** The download file is very large (about 1GB).

- 2 Click **Start**, point to **All Programs**, point to **Windows OPK** or **Windows AIK**, and then click **Windows PE Tools Command Prompt**.

 **NOTE:** Opening the command prompt window automatically sets environment variables to point to all the necessary tools. By default, all tools are installed at C:\Program Files\\Tools, where <version> can be Windows OPK or Windows AIK.

- 3 At the command prompt, run the command:

```
copype.cmd x86 <dest>
```

where <dest> is a local directory for this procedure, such as c:\winpe_x86. This script creates the <dest> directory and copies in all necessary files for the x86 architecture to the directory. In this example, the following directories are created:


```
\winpe_x86
\winpe_x86\ISO
\winpe_x86\mount
```


- 4 At the command prompt, mount the base Windows PE image (Winpe.wim) to the \mount directory by using **ImageX**:

```
imagex /mountrw c:\winpe_x86\winpe.wim 1
c:\winpe_x86\mount
```

- 5 Copy the following files from the update DVD to the \winpe_x86\mount\windows\system32\ directory:

```
winpeshl.ini
DellImageDeploy.exe
Comctl32.dll
Oledlg.dll
Wimgapi.dll
```



 **NOTE:** Image preparation, performed in the next step, is not required for the Dell Image Deployment tool. Skipping this step allows future updates to be added to your image by simply remounting `boot.wim` and copying the update files to the correct directories.

- 6 Prepare the image with the `peimg /prep` command. This command removes non-installed packages from the image to reduce the size of the final image:

```
peimg /prep c:\winpe_x86\mount\Windows
```

- 7 Commit the changes to the original image file (`winpe.wim`) using the `ImageX /unmount` option with the `/commit` option:

```
imagex /unmount c:\winpe_x86\mount /commit
```





- 8 Replace the default `Boot.wim` in the `\winpe_x86\ISO` directory with your new customized image. The image must be called `Boot.wim`.


 **CAUTION: When a UFD device is formatted, all files on the device are erased.**

- 9 Prepare the UFD device. Use Diskpart to format the UFD with a Windows Vista or Windows PE environment.

- a Within a Windows Vista operating system or Windows PE session, insert your UFD device.
- b Format the entire UFD as a single FAT32 drive. The following example assumes the UFD is `disk 1`. Open a command window and enter the following:

```
diskpart
select disk 1
clean
create partition primary size=<size of device>
select partition 1
active
format fs=fat32
assign
exit
```






- 10 On the workstation computer, copy the entire `\winpe_x86\ISO` directory to the UFD device. You can create the directory structure manually, or use `xcopy` to replicate the entire structure and contents of `\ISO`. If using `xcopy`, enter:

```
xcopy c:\winpe_x86\iso\*.* /s /e /f f:\
```


where `c` is the letter of your technician computer hard disk and `f` is the letter of the UFD device.

- 11 Remove the UFD device from the technician computer.


Re-Imaging Windows on the FX160 Computer With a UFD Device


 **CAUTION: Re-imaging your FX160 computer will erase all data from the hard drive or flash card. Back up your system to an external device before re-imaging your computer.**

- 1 Power off the FX160 computer.
- 2 Plug the UFD device with the bootable Windows XP Embedded image update into a USB port.
- 3 Power on the FX160 computer. When the BIOS window options list appears (in the upper right-corner of the screen) press `<F12>` to access the Boot Menu.
- 4 In the Boot Device selection window, use the arrow keys to highlight the UFD device with the Windows XP Embedded image update, then press `<Enter>`. When the Windows PE system is initialized, the Windows XP Embedded imaging tool is launched.
- 5 To save the current FX160 system image, click the **Capture System Image** button and follow the prompts to save the system image to an external device. When the capture operation completes, the imaging tool window reappears.

 **CAUTION: By default, all existing files are erased and system images are installed on the first available boot drive as configured in the BIOS System Boot Device Priority. Back up your system to an external device before re-imaging your computer.**

- 6 To install a new system image, click the **Install System Image** button. In the browse window, select the system image to install, then click **Install**.
- 7 When the installation completes, restart the system, booting from the drive that was imaged.





Re-Imaging the FX160 Computer With SUSE Linux Enterprise Thin Client

The FX160 computer can be re-imaged with an SLETC update using a bootable USB flash drive built with the update CD and either a Linux or Windows computer system. After the FX160 computer is booted to the USB flash drive, the Thin Client Imaging utility is used to copy SLETC to the FX160 flash card (hard drive). The minimum size for the USB flash drive is 512MB.

Create a Linux Bootable USB Flash Drive With Linux

The update CD provided includes these three files:

- Documentation (* .pdf).
- SLETC update file (* .raw). The name of this file reflects the revision level of SLETC.
- Windows USB flash drive image installer (USBDiskImageTool.exe).

Only the update file is needed to build the bootable USB flash drive.



CAUTION: This procedure formats the UFD device used to load the system image. All files on the device are erased.




CAUTION: Some of the commands entered in this procedure are performed with administrative privileges. Use extreme care to prevent typing errors, which could result in serious damage to your Linux operating system.


- 1 On the Linux desktop, open a terminal window.
- 2 If not logged in as a "root" user, enter the command:

```
su -
```
- 3 Mount the CD-ROM containing the SLETC update. Many Linux distributions mount the CD automatically when it is loaded. For this procedure, it is assumed that the CD is mounted as:

```
/media/Novell_SLETC_for_Dell
```
- 4 Insert a USB flash drive into a USB port.
- 5 Determine whether or not the USB flash drive is mounted:
 - a Enter:

```
mount
```
 - b Examine the output to determine if the USB flash drive is mounted.





To create the bootable USB flash drive with Windows, use the program **USBDiskImageTool.exe** to write the SLETC file to the USB flash drive:



NOTE: The Windows operating system used to build the bootable USB flash drive must include Microsoft .NET Framework v2.0 or later.



CAUTION: This procedure formats the USB flash drive used to load the system image. All files on the drive are erased.


- 1 On a system running Windows XP or Windows Vista, insert the SLETC update CD into a CD-ROM drive, and the USB flash drive into a USB port.
- 2 Open an Explorer window that shows the contents of the update CD.
- 3 Find and open **USBDiskImageTool.exe**. If using Windows Vista, respond appropriately to User Access Control messages to continue.
- 4 In the **USB Disk Image Tool** window, click the **Browse** button and select the SLETC update file on the update CD.
- 5 In the field **Choose a USB device**, use the pull-down menu to select the USB flash drive.
- 6 Click **Write Disk Image** to initiate the write operation. Allow the **Write...** and **Verify...** operations to complete fully before removing the USB flash drive.
- 7 When the message **Disk was imaged successfully** message appears, click **Close**.
- 8 Remove the USB flash drive and the update CD from the Windows system.


Re-Imaging SLETC on an FX160 Computer With a USB Flash Drive




CAUTION: Re-imaging your FX160 computer will erase all data from the hard drive or flash card. Back up your system to an external device before re-imaging your computer.

- 1 Shut down the operating system and power off the computer.
- 2 Insert the bootable flash drive with the SLETC image into a USB port.
- 3 Power on the FX160 computer.
- 4 When the BIOS window options list appears (in the upper right-corner of the screen) press <F12> to access the Boot Device menu.





- 5 In the **Boot Device** selection window, use the arrow keys to highlight the USB flash drive with the SLETC image, then press <Enter.>
 - 6 Allow the SLETC operating system finish booting, then click the **Computer** button on the desktop. In the window that opens:
 - a Click **More Applications**.
 - b Click **Thin Client Image**.
 - 7 In the **Thin Client Image** window:
 - a Find the **Target** pull-down menu and select **Hard Drive**.
-  **CAUTION: When the disk image is being written, do not perform other operations with your computer.**
- b Click and hold the **Install Image** button for one second to initiate the write operation.
 - c In the **Warning** window, click **Erase and Install Image**. A **Thin Client Image Tool** window will open.
 - d When the write disk image operation completes, the **Thin Client Image Tool** window closes.
 - e Close the **Thin Client Imager** window.
- 8 Shut down the computer.
 - 9 Remove the bootable USB device from the computer.
 - 10 Boot the system using the internal flash card.

Automated Deployment


The installed image in the FX160 computer includes a deployment server agent that interacts with an Altiris Deployment Server, providing an environment for the automated deployment of system updates including system image, application software, BIOS updates and configuration, etc.






The FX160 computer includes a Preboot Execution Environment (PXE) capable network interface. However, for improved security Dell advises that systems setup for automated deployment are configured to use an automation partition instead of PXE.










Documentation for Altiris software can be found at:




<http://www.altiris.com/Support/Documentation.aspx>

Your FX160 system is licensed to use the Altiris Deployment Server.









Printed in the U.S.A.

www.dell.com | support.dell.com



0H310KA01

